



SHIN • ICHI

Symbol Of Arts



CATALOGUE

Curtain Accessories

Tassel
Rollet
Lace
Hook



TASSEL

ST 02

ST 04



ST 2-1 2-2 2-3 2-4 2-5 2-6 2-7 ST 4-1 4-2 4-3 4-4 4-5

ST 10



ST 10-1 2 3 4 5 6 7 8 9 10 12 14 16 17

ST 14



ST 14-1

14-2

14-3

14-4

14-5

14-6

ST 15



ST 15-1

15-2

15-3

15-4

15-5

15-6

ST 16

ST 18



ST 16-1

16-2

16-3

16-4

16-5

16-6

ST 18-1

18-2

18-3

18-4

18-5

18-6



ROLLET

STANDARD



RO-05



RO-06



RO-07



RO-08



RO-09



RO-11



RO-12



RO-01



RO-13



RO-16



ROB-05

ROB-02

ROB-01

ROB-06



ROEC-06

ROEC-05

ROEC-02

ROEC-01

ROEC-03



ROEC-15

ROEC-16



ROEC-10

ROEC-12

ROEC-17

ROEC-19



ROEC-25

ROEC-24

ROEC-26



CURTAIN HOOK



CH-1324



CH-1325



CH-1326



CH-1327



CH-1328



CH-1329



CH-1330



CH-1332



CH-1333



CH-3105R



CH-3106R



CH-3107R



CH-3105



CH-3106



CH-3107



CH-3108



CH-3318



CH-3319



CH-3320

CURTAIN HOOK



A-1106



A-1107



A-1108



A-1107P



CH-1314



CH-1315



CH-1316



CH-1317



CH-1113



CH-1114



CH-1115



CH-3109



CH-3110



A-1506P



A-1512



A-1619P



CH-1522



A-1507P



A-1513



A-1620P



CH-1523



A-1508P



A-1514



A-1621P



CH-1524



A-1505



A-1616P



A-1623P



A-1502



A-1503



A-1504



A-1506



A-1617P



A-1624P



A-1501



A-1504



A-1508



A-1618P



A-1625P



1519



1520




1521



STICK



TUSUK KONDE





LACE &

KEY TASSEL



TL-1



TL-2



TL-3



TL-4



TL-5



TL-7



TL-8



TL-9



TL-10



TL-11



TL-12



TL-13



TL-14



RW-1



RW-2



RW-3



RW-4



RW-5



RW-6

LACE & KEY TASSEL



RD-1



RD-2



RD-3



RD-4



RD-5



RD-6



RL-1



RL-2



RL-3



RL-4



RL-5



RL-6



EC-1



EC-2



EC-3



EC-4



EC-5



EC-6



EC-7



BC-1



BC-2



BC-3



BC-4



BC-5



BC-6



BC-7

LACE & KEY TASSEL



CT-1



CT-2



CT-3



CT-4



CT-5



CT-6



CT-7



EP-1



EP-2



EP-3



EP-4



EP-5



EP-6



SS-1



SS-2



SS-3



SS-4



SS-5



SS-6



SS-7



SS-8



SS-9



SS-10



SS-11



SS-12



SS-13



GD-1



SS-14



GD-2



GD-3



GD-4



GD-5



GD-6



GD-7



GD-8



GD-9



GD-10



GD-11

LACE & KEY TASSEL



RG-1



RG-2



RG-3



RG-4



RG-7



RG-8




RG-9



RG-10



RG-11



RG-13



RG-14



RG-15



RG-16



RG-17



RG-18




BB-1



BB-2



BB-3



BB-4



BB-5



BB-6



BB-7



BB-8



BB-9



BB-10



BB-11



BB-12



BB-13



BB-14



B-2



B-3



B-6



B-8



B-9



H-1



H-6



H-11



H-13



H-16



SHIN-ICHI[®]

Symbol Of Arts



SHIN-ICHI[®]

Symbol Of Arts

